

Section C GEARBOX UNIT — ALL MODELS

INDEX

Page	C-13	Stripping
	C-13	Dismantling
	C-15	Assembling
	C-17	Fitment
	C-24	Main gear change lever
	C-24	Overhaul
	C-24	Reverse stop
	C-24	Adjustment
	C-17	Transfer box
	C-17	Removal
	C-18	Stripping
	C-19	Assembling
	C-20	Fitment

Page	C-25	Fitting synchronising clutch assembly
	C-14	Tightening transfer drive gear securing nut
	C-15	Adjusting 2nd speed gear stop bolt
	C-16	Removing intermediate gear shaft
	C-17	Fitting transfer box output shaft protection cap
	C-18	Removing transfer box output shaft front bearing outer race
	C-18	Removing transfer box output shaft front bearing inner race
	C-19	Removing transfer box output shaft
	C-20	Adjusting transfer box output shaft end-float
	C-21	Adjusting reverse gear stop bolt
	C-22	Setting the link pin
	C-23	Setting transfer and dog clutch selector shaft
	C-24	Cross-section of reverse stop
	C-24	Adjusting reverse stop

Page	C-2	Layout of the gearbox unit: casings
	C-4	Layout of the gearbox unit: main gear change lever and selectors
	C-6	Layout of the gearbox unit: front output shaft housing and controls
	C-8	Layout of the gearbox unit: main gear change lever and selectors
	C-10	Cross-section of gearbox unit: elevation
	C-11	Cross-section of gearbox unit: plan
	C-12	Cross-section of gearbox unit: controls
	C-13	Gearbox unit mounting rubbers
	C-14	Removing the transfer drive gear securing nut
	C-14	Removing layshaft rear bearing outer race
	C-15	Checking mainshaft gear end-float
	C-15	Measuring mainshaft bush end-float

Fig.



Page

Fig.

Page

LIST OF ILLUSTRATIONS

Fig. C-1—Layout of the gearbox unit casings



Key to Fig. C-1

1	Gearbox casing assembly	1	Transfer box casing assembly
2	Stud for top cover and gear change plate	2	Stud for intermediate shaft
3	Stud, short, for transfer casing	3	Stud for speedometer housing, short
4	Stud for bell housing	4	Stud for mainshaft housing
5	Dowel locating top cover	5	Stud for top cover plate
6	Dowel locating transfer casing	6	Stud, short, for transfer shaft housing
7	Top cover for gearbox	7	Stud for engine mounting
8-9	Fixings for top cover	8	Stud for bottom cover
10	Inspection cover plate for selectors	9	Dowel locating speedometer housing
11	Set screw fixing cover plate	10	Bush for shaft guide
12	Oil filler cap	11	Housing assembly for speedometer pinion
13	Joint washer for cap	12	Insert for pinion
14	Plug for retaining spring	13	Stud for transmission brake
15	Retaining spring for cap	14	Mudshield for housing
16-17	Fixings for spring	15	Shim for speedometer pinion housing
18	Oil level dipstick	16-17	Fixings for housing
19	Drain plug for gearbox	18	Housing assembly, rear mainshaft bearing
20	Washer for plug	19	Bush for housing
21	Bell housing assembly	20	Retaining plate, inner
22	Stud for withdrawal race housing	21	Bearing for mainshaft
23	Dowel locating gearbox	22	Retaining plate, outer
24	Joint washer, bell housing to gearbox	23	Clip fixing bearing
25-26	Fixings for gearbox casing	24	Joint washer for bearing housing
27	Top cover for bell housing	25-55	Fixings for transfer box
28	Rubber seal for top cover	26-52	Fixings for transfer box
29	Centre for dust cover	27-48	Fixings for feet
30	Grommet for bell housing hole	28-46	Self-locking nut } adjuster
31	Grommet for bell housing shaft	29-45	Plain washer } For
		30-44	Adjuster for mounting foot
		31-43	Rear mounting foot R.H.
		32-42	Rear mounting foot L.H.
		33-41	Oil level plug
		34-40	Joint washer for plug
		35-39	Plug, top and bottom
		36-38	Fixings for cover
		37-36	Joint washer for bottom cover
		38-35	Cover plate, bottom, for transfer box
		39-34	Fixings for plate
		40-32	Joint washer for cover plate
		41-31	Cover plate for transfer gear change
		42-30	Fixings for cover plate
		43-28	Joint washer for cover plate
		44-27	Cover plate for P.T.O. selector
		45-26	Fixings for housing






Fig. C-2—Layout of the gearbox units: shafts and gears

Key to Fig. C-2

- | | | | |
|-------|--|-------|---------------------------------------|
| 1 | Primary pinion and constant gear | 44 | Distance piece, rear of mainshaft |
| 2 | Shield for primary pinion | 45 | Mainshaft gear for transfer box |
| 3 | Ball bearing for primary pinion | 46-47 | Fixings for gear |
| 4-5 | Fixings for bearing | 48 | Shaft for reverse gear |
| 6-8 | Fixings for bearing | 49 | Reverse wheel assembly |
| 9 | Layshaft | 50 | Bush for reverse wheel |
| 10 | Mainshaft | 51 | Gear, intermediate |
| 11 | Peg for 2nd gear thrust washer | 52 | Roller bearing for intermediate gear |
| 12 | Peg for mainshaft distance sleeve | 53 | Thrust washer for intermediate gear |
| 13 | Thrust washer for 2nd speed gear | 54 | Shim for intermediate gear |
| 14 | 1st speed layshaft gear | 55 | Shaft for intermediate gear |
| 15 | 1st speed mainshaft gear | 56 | Sealing ring for intermediate gear |
| 16 | 2nd speed layshaft and mainshaft gear | 57 | Retaining plate for shaft |
| 17 | Split ring for 2nd speed layshaft gear | 58-59 | Fixings for plate |
| 18 | 3rd speed layshaft and mainshaft gear | 60 | Low gear wheel |
| 19 | Distance sleeve for mainshaft | 61 | High gear wheel |
| 20 | Thrust washer for 3rd speed mainshaft gear | 62 | Output shaft, rear drive |
| 21 | Spring ring fixing 2nd and 3rd mainshaft gears | 63 | Thrust washer for high gear wheel |
| 22 | Sleeve for layshaft | 64 | Circlip fixing washer to shaft |
| 23 | Bearing for layshaft, front | 65 | Bearing for output shaft, front |
| 24-26 | Fixings for bearing to layshaft | 66 | Circlip fixing bearing to case |
| 27 | Bearing plate assembly for layshaft | 67 | Bearing for output shaft, rear |
| 28 | Stud for bearing cap | 68 | Oil seal for output shaft |
| 29 | Distance piece for layshaft | 69 | Speedometer worm complete |
| 30 | Retaining plate for layshaft front bearing | 70 | Flange for output shaft, rear drive |
| 31-32 | Fixings for cap and bearing | 71 | Mudshield for flange |
| 33 | Bearing for layshaft, rear | 72 | Fitting bolt for brake drum |
| 34 | Synchronising clutch | 73 | Retaining flange for brake drum bolts |
| 35 | Detent spring for clutch | 74 | Fitting bolt for propeller shaft |
| 36 | Roller bearing for mainshaft | 75 | Circlip retaining bolts and flange |
| 37 | Ball bearing for mainshaft | 76-78 | Fixings for flange |
| 38 | Housing for mainshaft bearing, rear | 79 | Speedometer pinion |
| 39 | Peg, housing to casing | 80 | Retaining plate for pinion |
| 40 | Circlip, bearing to housing | 81 | Screw fixing plate to housing |
| 41 | Circlip, housing to casing | 82 | Sleeve for pinion |
| 42 | Oil seal for rear of mainshaft | 83 | Sealing ring for sleeve |
| 43 | Oil thrower for mainshaft | 84 | Joint washer for sleeve |
| | | 85 | Oil seal for pinion |


Fig. C-3—Layout of the gearbox unit: front wheel drive, transfer gear controls and front output shaft and housing



Key to Fig. C-3

1	Output shaft housing assembly	31	Link for selector shaft
2	Stud for oil seal retainer	32-33	Fixings for link
3	Front output shaft assembly	34	Lever assembly, four wheel drive
4	Bush for shaft	35	Bush for lever
5	Oil thrower for output shaft	36	Special bolt, lever to housing
6-7	Fixings for oil thrower	37	Locking pin, four wheel drive lever
8	Bearing for front output shaft	38	Sealing ring, four wheel drive locking pin
9	Oil seal for shaft	39-40	Fixings for locking pin
10	Retainer for oil seal	41	Selector rod, four wheel drive
11	Mudshield for retainer	42	Clevis complete for rod
		43	Split pin for clevis
		44	Spring for selector rod
		45	Special bush for spring
		46	Control knob for rod
		47	Locknut for knob and clevis
		48	Transfer gear change lever complete
		49	Spring for transfer gear change lever
		50	Knob for gear change lever
		51	Locknut for knob
		52	Bracket for gear change lever
		53	Distance piece for bracket
		54-56	Fixings for bracket
		57-58	Fixings for gear lever
1	Selector shaft, four wheel drive		
2	Selector fork complete, four wheel drive		
3	Bush for selector fork		
4	Spring for selector fork		
5	Block for selector shaft		
6-8	Fixings for block		
9	Selector shaft, transfer gear change		
10	Sealing ring for transfer gear change shaft		
11	Selector fork, transfer gear change		
12	Set bolt fixing fork		
13	Distance tube for transfer selector shaft		
14	Locating bush for selector shaft spring		
15	Spring for gear change selector shaft		
16	Connector, gear change to pivot shaft		
17	Block for selector shaft		
18-20	Fixings for block		
21	Pivot shaft for selector shafts		
22	Coupling, selector shafts to pivot		
23-25	Fixings for coupling		
26-27	Fixings for pivot shaft		
28	Plunger for transfer selector shaft		
29	Spring for plunger		
30	Plug		

Fig. C-4—Layout of the gearbox unit: main gear change lever and selectors



Key to Fig. C-4

1	Selector fork, 3rd and 4th speed	1	Gear change lever
2	Shaft for fork, 3rd and 4th speed	2	Housing for lever
3	Selector fork, 1st and 2nd speed	3	Locating pin for lever ball
4	Shaft assembly for fork, 1st and 2nd speed	4	Spherical seat for gear lever
5	Interlocking pin	5	Retaining spring for lever
6	Peg fixing interlocking pin	6	Retaining plate for spring
7	Selector fork, reverse	7	Clip fixing retaining plate
8	Shaft for fork, reverse	8	Knob for lever
9	Set bolt fixing forks to shafts	9	Locknut for knob
10	Stop for 2nd speed	10	Mounting plate for gear change
11-12	Fixings for stop	11-12	Fixings for housing
13	Interlocking plunger	13-14	Fixings for mounting plate
14	Steel ball for selectors	15	Reverse stop hinge complete
15	Selector spring, forward	16	Adjusting screw
16	Selector spring, reverse	17	Locknut
17	Retaining plate L.H.	18	Bracket for reverse stop spring
18	Retaining plate R.H.	19	Spring for reverse stop
19	Rubber grommet	20-22	Fixings for hinge and bracket
20-21	Fixings for retaining plates		
22	Seal for selector shafts		
23	Cork seal for reverse shaft		
24	Retaining plate for sealing ring		
25-26	Fixings for retaining plate		
27	Set bolt		
28	Locknut		
29	Adjustable stop for reverse selector shaft		
30	Locknut for stop		

For selector
springs, side

For hinge




Fig. C-5—Cross-section of gearbox unit: elevation

Fig. C-6—Cross-section of gearbox unit: plan





Fig. C-7—Cross-section of gearbox unit: controls



Gearbox and transfer box assembly

To remove Operation C/2

1. Remove the hood, hard top or cab, for convenience in working.
2. Remove the front wheel drive control knob, locknut and spring; remove the knob and locknut from the transfer gear change lever.
3. Remove the floor board assembly and gearbox cover, Section R.
4. Remove the seat box complete, Section R.
5. **L.H.D. models only.** Remove the hand brake lever and linkage, Section H.
6. **R.H.D. models only.** Remove the hand brake rod and the expander rod from the relay lever.
7. Disconnect the front axle propeller shaft, rear axle propeller shaft and rear power take-off propeller shaft (if fitted), at the gearbox end.
8. Disconnect the clutch operating hose at the slave cylinder, remove the split pin and withdraw the pin fixing the connecting tube to the clutch cross and operating shafts, then remove the nuts and washers securing the bracket to the bell housing and remove the bracket complete with slave cylinder.
9. Disconnect the speedometer cable at the gearbox and withdraw the cable clear of the gearbox.
10. Remove the remaining nuts and plain washers fixing the bell housing to flywheel housing, then remove the gearbox unit bearer bolts, top bearer rubbers, washers, shims and distance tubes.
11. Place a suitable sling around the gearbox unit, raise it approximately 1 inch.
12. Place a jack under the rear end of the engine; this prevents any strain being taken on the primary pinion shaft.
13. Withdraw the gearbox unit and remove it from the vehicle.

To refit Operation C/4

1. Reverse the removal procedure.
2. The nip on the gearbox unit mounting rubber pads is adjusted by the addition or removal of shims on the top of the central distance tube. The correct setting is with the top shim approximately 1/16 in. (1.5 mm) below the top face of the upper rubber pad.

ALL MODELS

Note: The rear mounting brackets are adjustable laterally, to facilitate alignment with the mounting rubbers.

3. If necessary, refill the main gearbox, 2 1/2 pints (1.5 litres) and transfer box, 4 1/2 pints (2.5 litres) with oil.
4. Adjust the transmission brake, Section H.
5. Adjust the four-wheel drive control rod, Operation C/28.
6. Bleed the clutch system, and adjust the pedal movement as necessary, Section B.

Main gearbox

To remove Operation C/6

1. For removal procedure, see Operation C/2.

To strip Operation C/8

1. Mount the gearbox on a suitable stand.
2. Drain off the gearbox and transfer box oil.
3. Remove the main gear change lever assembly, then the reverse stop hinge, Operation C/30.
4. Remove the transfer box and front output shaft housing complete, Operation C/14.


Dismantle the main gearbox as follows:

5. Disconnect the connecting tube from the clutch cross-shaft.
6. Remove the dust-proofing grommets from the bell housing apertures.
7. Remove and strip the clutch withdrawal unit from the bell housing, Section B.
8. Remove the oil filler cap and joint washer from the gearbox top cover.
9. Remove the filler cap retaining clip.
10. Remove the plug retaining the 1st/2nd speed selector spring in the top cover and withdraw spring.

Note: To prevent the selector ball falling into the gearbox, with the top cover removed, pack the hole with grease.

Fig. C-8—Gearbox unit mounting bolts and pads—2 litre petrol only

- A—Plain washer (upper)
- B—Rubber washer
- C—Distance tube
- D—Shim
- E—Top rubber
- F—Bottom rubber
- G—Plain washer (lower)
- H—Front bolt
- J—Rear bolt
- K—Spring washer
- L—Self-locking nut



11. Remove the retaining plates for the side selector springs, the rubber grommets and the 3rd/4th top cover.

12. Remove the selector cover plate from the gearbox top cover.

13. Remove the two selector shaft end cover securing set bolts.

14. Remove the gearbox top cover, together with the upper selector end cover. Remove the two selector balls and locking plunger from the gearbox and the 1st/2nd speed selector ball from the top cover. Remove the 2nd gear stop from the top cover.

15. Select 1st gear (centre selector to rear); remove the reverse gear selector by lifting and turning the selector shaft one quarter of a turn to the left. Move the 1st/2nd speed selector to the neutral position and remove it; remove the 3rd/4th selector cover. Remove the reverse selector fork and the rubber sealing ring from the shaft.

16. Withdraw the reverse selector fork and the 1st/2nd selector shaft. Withdraw the selector fork and the rubber sealing ring from the shaft.

17. Remove the 2nd speed stop from the end of the rubber sealing ring from the shaft.

18. Withdraw the 3rd/4th selector fork and the castle nut from the front of the layshaft. (To lock the shaft for nut removal, select top and 2nd speeds simultaneously.)

19. Remove the nut from the front of the layshaft. Remove the needle roller bearing from the front end of the mainshaft. Remove the constant gear and conical distance piece from the bell housing.

20. Remove the nut at the rear of the mainshaft retaining the transfer drive gear. Withdraw the gear and distance piece and oil flinger from the mainshaft.

21. Remove the bell housing complete with joint washer, tapping the layshaft out of the front bearing, so that it remains in the gearbox. Remove the needle roller bearing from the front end of the mainshaft. Remove the constant gear




Fig. C-9—

Removing the transfer drive gear securing nut

22. Remove the layshaft front bearing retaining plate.

23. Remove the layshaft bearing plate; press out the layshaft front bearing, remove the pinion bearing retaining plate. Press out the primary pinion and bearing from the bell housing.

Remove the nut securing the primary pinion bearing; press the bearing and shield off the pinion shaft. (The nut has a left-hand thread.)

24. Remove the synchronising clutch unit from the mainshaft and then withdraw the layshaft complete from the gearbox and strip it as follows:

25. Remove the distance sleeve. Remove the 3rd and 2nd speed gears. Remove the split ring retaining the 2nd speed gear. Press off the rear bearing and 1st speed gear.

26. Drive out the mainshaft complete from the rear and strip it as follows:

27. Remove the 1st speed gear. Prise out the spring ring inside the 3rd speed gear cone and discard it; remove the 3rd speed gear thrust washer and 2nd speed gear. Remove the distance sleeve and 2nd speed gear. Remove the peg locating the distance sleeve and withdraw the located 2nd speed gear thrust washer.

28. Remove the circlip retaining the mainshaft rear bearing housing to the rear face of the gearbox casing. Tap out the peg-located bearing housing complete from the rear. Remove the oil seal from the housing. Remove the circlip retaining the bearing in the housing and press out the bearing.

29. Drive out the reverse gear shaft from inside the gearbox; the gearbox casing must be warmed to facilitate this operation. Remove the reverse gear and, if necessary, press out the bush from the gear.

30. To remove the outer race of the layshaft rear bearing from the gearbox casing, proceed as follows:

Make a plunger (preferably from hardwood) about 12 in. (300 mm) long and approximately $1\frac{1}{16}$ in. (43.50 mm) in diameter, i.e. to just fit




Fig. C-10—

Removing layshaft rear bearing
A—Plunger
outer race

13. While pressing the third speed gear hard against the bush shoulder, the end-float of the second speed gear, measured between the gear and the bush shoulder, should be .004 to .007 in. The third speed gear end-float should be the same, measured with the second speed gear pressed hard against the bush shoulder.




Fig. C-11—Measuring mainshaft gear end-float

14. If the end-float of either gear is insufficient, a new mainshaft bush must be fitted; if excessive, it may be reduced by rubbing down the end face of the bush.

15. Remove the spring ring, take off the thrust washer, bush and gears, and replace the bush and washer, securing with the old spring ring.

16. An end-float of .001 to .008 in. for the mainshaft bush is allowed, but this should be kept as low as possible by the use of the thrust washers, which are supplied in four thicknesses—.125 in., .128 in., .130 in. and .135 in.




Fig. C-12—Measuring mainshaft bush end-float

17. When the end-floats are correct, fit the rear thrust washer and the bush locating peg. Assemble the bush and gears and slide on the front thrust washer with its groove in line with the small slot in the bush.

18. Secure the assembly with a new spring ring.

19. Slide the first speed mainshaft gear over the mainshaft splines with its internally splined flange to the front; check that the internal splines mesh easily with the second speed gear at all positions of a complete revolution.

20. Insert the mainshaft complete into the gearbox casing and tap the rear end of the shaft home into its bearing; the shaft must be a *drive fit* in the bearing.

21. Assemble the layshaft as follows:

Slide the first speed layshaft gear over the splines on the rear of the layshaft with the chamfered end of the teeth to the front and fit the rear bearing inner race on to the shaft. The bearing must be a *tap fit* on the shaft.

into the outer race. Stand the gearbox casing on end and fill the race housing with thick oil, insert the plunger and tap it down sharply. In most cases the oil will force the outer ring upwards out of the casing; if necessary, the gearbox casing may be warmed to facilitate removal of the race.

To assemble

Operation C/10

1. Wash all the component parts thoroughly and lay them out for inspection. Renew all lock-washers, split pins and spring rings.
2. Check all the bearings for wear and damage, and renew them as necessary.
3. Check all the gears for damage marks and rectify or renew them as necessary. The constant, second and third speed gears are only supplied in mated pairs; all other gears may be replaced singly.

4. Examine the casing for signs of damage or cracks and renew it as necessary. A casing may also be scrap as a result of excessive wear in a bearing bore; such wear will be obvious during the course of assembly.

5. Press the layshaft rear bearing outer race into the gearbox casing with the lipped edge to the rear. It must be a *drive fit*. It may be necessary to warm the casing to assist in this operation.

6. If necessary, renew the reverse gear bush, bell out its extremities and ream it in position to .812 in. (20 mm). The bush should be a *press fit* in the gear. Place the reverse gear (with the smaller wheel to the rear) in position in the gearbox and drive the shaft through the gearbox casing and the gear. It will be necessary to warm the casing to assist in this operation. The shaft must be a *drive fit* in the casing.

7. Press the mainshaft rear bearing into the bearing housing until it abuts the flange in the housing bore; the bearing must be a *press fit* in the housing. Secure the bearing with a circlip.

8. Smear the outer diameter of the oil seal with jointing compound and press it into the other end of the housing, with the knife edge inwards.

9. Fit the location peg in the bearing housing and push the complete housing into the gearbox casing from the inside, until the housing flange abuts the casing. The housing must be a *push fit* in the casing; secure the housing with a circlip.

Mainshaft

10. If removed, replace the rear thrust washer. Do not fit the large bush locating peg at this stage.

11. Slide on the mainshaft bush with the large locating slot to the rear, together with the second speed gear, synchronomesh cone to the rear.

12. Place the third speed gear on the bush with the gear wheel against the shoulder, and secure with the second thrust washer and the old spring ring.

Fit the split ring retaining the 2nd speed gear and slide the gear on to the shaft, with its flange to the front, over the split ring; ensure that the ring beds well into its groove and does not foul or tilt the gear. Slide the 3rd speed gear on to the shaft with its flange to the front, followed by the distance tube, constant gear and conical distance piece. Press the layshaft front bearing on to the end of the layshaft and lock up the whole assembly tightly by means of the plain washer and castle nut. Ensure that the layshaft assembly is locked up tightly and that the gears are not tilted by excessive run-out, either on their faces or those of the distance sleeve.

22. Should the gears have any end-float, this condition must be rectified by fitting a new distance tube.

23. Remove the castle nut, plain washer, bearing, conical distance piece and constant gear from the end of the shaft and fit the rest of the assembly in the gearbox casing, engaging the constant mesh gears.

Assemble the primary shaft as follows:

24. Press the primary pinion bearing on to the pinion shaft until it abuts the shoulder. The bearing must be a *light press fit* on the shaft. Secure the bearing by means of the lockwasher and locknut.

Assemble the bell housing as follows:

25. Press the primary shaft and bearing into the bell housing. The bearing must be a *press fit* in the housing. It may be necessary to warm the bell housing to assist in this operation. Fit the layshaft bearing plate.

26. Fit the pinion bearing retaining plate.

27. Press the layshaft front bearing into the bell housing until it is flush with the rear face of the housing. The bearing must be a *press fit* in the housing; it may be necessary to warm the bell housing to assist in this operation. Fit the layshaft bearing plate.

28. Check and renew the synchronising clutch unit detent spring, if necessary. Fit the synchronising clutch assembly over the mainshaft splines, with the recessed portion towards the 3rd speed gear (Fig. C-13).

29. Place the needle roller bearing over the front of the mainshaft and place the conical distance piece and constant gear in mesh with the primary pinion on the rear face of the bell housing. Offer the bell housing and joint




Fig. C-13—Fitting synchronising clutch assembly




Fig. C-14—
Tightening transfer drive gear
securing nut

washer to the gearbox casing, locating the dowel and entering the housing lip into the casing; the front end of the layshaft is a *sliding fit* in the bearing inner member. Secure the housing to the gearbox casing.

Special fitting bolts are used for securing and locating the gearbox to bell housing. These bolts are accurately machined and must not be replaced by standard bolts.

30. With the bell housing secured, and the layshaft front bearing retaining plate fitted but not tightened, ensure that a minimum layshaft movement of .005 in. (.13 mm) is present, to ensure adequate bearing clearance. If the layshaft bearings are binding, remove the bell housing and retaining plate and fit a thinner conical distance washer from the range available, *i.e.*, .312 in. (8 mm), .332 in. (8.5 mm) and .352 in. (9 mm).

Refit the bell housing and retaining plate over the layshaft by selecting top and second simultaneously, and tighten the layshaft securing nut to 75 lb/ft (10 kg/m), if necessary tightening to the next split pin hole. This will draw the layshaft forward, so allowing a minimum of .005 in. (.13 mm) clearance for the end bearing.

31. Examine the distance piece for the rear end of the mainshaft, this acts also as a track for the oil seal and must be rectified or renewed if damaged in any way on its outer diameter. Place the distance piece and oil flinger over the shaft and fit the transfer drive gear with its splined flange to the rear; secure the gear with the tab washer, shim and nut using special spanner Part No. 263056 (Fig. C-14).

Assemble the main selectors as follows:

32. Fit the rubber sealing ring and 3rd/4th selector fork to the selector shaft; fit the rubber sealing ring and 1st/2nd selector fork to the selector shaft and fit the 2nd speed stop to the end of the shaft. Fit the rubber sealing ring and reverse selector fork to the selector shaft.

43. Fit the connecting tube to the clutch cross-shaft.
 44. Refit the transfer box and front output shaft housing complete. Operation C/20.
 45. Refit main gear change lever. Operation C/30.
 46. Fit and adjust reverse stop hinge. Operation C/32.
- To refit**
 Operation C/12
1. Replace the complete gearbox and transfer box assembly in the vehicle. Operation C/4.
- To remove**
 Operation C/14
1. Drain off the transfer box oil.
 2. Remove the floor board assembly and gearbox cover. Section R.
 3. Remove seat box. Section R.
 4. Disconnect the front propeller shaft at the output shaft housing end.
 5. Disconnect the rear propeller shaft and rear power take-off propeller shaft (if fitted) at the gearbox end.
 6. **R.H.D. models.** Disconnect the hand brake expander rod from the relay lever.
 7. **L.H.D. models.** Disconnect the hand brake rods from the relay lever. Remove the hand brake cross-shaft. Section H.
 8. Disconnect the speedometer cable.
 9. Remove the transfer box output shaft driving flange complete with brake drum.
 10. Remove the brake back plate and shield from the speedometer drive housing.
 11. Remove the transfer box bottom cover and joint washer.
 12. Remove the nut and spring washer securing the intermediate gear shaft retaining plate; extract the retaining plate stud and remove the plate.
 13. Remove the mainshaft rear bearing housing— or, if fitted, the power take-off drive unit assembly (Section T) and joint washer, and extract the intermediate gear shaft, complete with rubber seal, using special extractor Part No. 262772.
 14. Remove the intermediate gear cluster through the base of the casing, complete with a needle roller bearing at each end of its bore. Remove the bearings from the gear. Remove also the thrust washer and if fitted, a shim.
 15. Disconnect the earth lead at the transfer box.




Fig. C-15—Adjusting 2nd speed gear bolt

33. Place the lower selector end cover in position on the gearbox. Fit the 3rd/4th and 1st/2nd selectors; move the 1st/2nd selector to the 1st speed position (to the rear) and fit the reverse gear selector; move the 1st/2nd selector to the neutral position.
34. Fit the locking plungers between the selector shafts.
35. Fit the gearbox top cover. Fit the upper selector end cover and secure both halves.
Note: The gearbox casing and top cover are machined together and must not be renewed separately.
36. Replace the reverse and 3rd/4th speed selector balls and springs (the reverse spring is the stronger of the two); fit the rubber grommets and retaining plates.
37. Replace the 1st/2nd speed selector ball and spring in the top cover and fit the filler cap spring plug and spring.
38. Ensure that the operation of the selector mechanism is correct.
39. Fit the set bolt and locknut (acting as a 2nd speed stop) in the top cover. Select 2nd gear and adjust the stop bolt so that there is .002 in. (.05 mm) clearance between the bolt head and the stop on the selector shaft; tighten the lock-nut (Fig. C-15). The reverse stop bolt cannot be adjusted until the transfer box has been fitted. Operation C/20.
40. Assemble the clutch withdrawal unit. Section B.
41. Fit the clutch withdrawal unit to the bell housing.
42. Fit the dust-proofing grommets.

4. Disconnect the front propeller shaft at the output shaft housing end.
5. Disconnect the rear propeller shaft and rear power take-off propeller shaft (if fitted) at the gearbox end.
6. **R.H.D. models.** Disconnect the hand brake expander rod from the relay lever.
7. **L.H.D. models.** Disconnect the hand brake rods from the relay lever. Remove the hand brake cross-shaft. Section H.
8. Disconnect the speedometer cable.
9. Remove the transfer box output shaft driving flange complete with brake drum.
10. Remove the brake back plate and shield from the speedometer drive housing.
11. Remove the transfer box bottom cover and joint washer.
12. Remove the nut and spring washer securing the intermediate gear shaft retaining plate; extract the retaining plate stud and remove the plate.
13. Remove the mainshaft rear bearing housing— or, if fitted, the power take-off drive unit assembly (Section T) and joint washer, and extract the intermediate gear shaft, complete with rubber seal, using special extractor Part No. 262772.
14. Remove the intermediate gear cluster through the base of the casing, complete with a needle roller bearing at each end of its bore. Remove the bearings from the gear. Remove also the thrust washer and if fitted, a shim.
15. Disconnect the earth lead at the transfer box.




Fig. C-16—Removing intermediate gear shaft

16. Disconnect the two gearbox unit bearer bolts, the top plain washers, rubber washers, shims, if fitted, top rubbers and distance tubes.

17. Remove the transfer lever from the bracket fixed to the bell housing.

18. Position a jack under the gearbox and raise it sufficiently to enable withdrawal of transfer box and front output shaft housing unit.

19. Detach the transfer casing from the main gearbox, noting that the three self-locking

securing nuts are located inside the transfer casing. Remove the transfer casing and front output shaft housing unit complete from the vehicle.

To strip

1. Remove the speedometer drive pinion unit.

2. Withdraw the pinion from the sleeve. If necessary, remove the oil seal from the pinion sleeve. Remove rubber 'O' ring.

3. Remove the speedometer drive housing complete with shims, which should be preserved. If necessary, remove the front output shaft oil seal from the housing.

4. Withdraw the speedometer drive worm from the transfer box output shaft; this is a sliding fit on the shaft.


5. Remove the front output shaft housing complete with output shaft, front wheel drive dog clutch, dog clutch selector shaft and fork and the joint washer.

6. Remove the top cover plate from the transfer box.

7. Remove the transfer gear selector fork and shaft.
8. Remove the circlip retaining the front bearing outer race in the transfer casing.

9. Drive out the transfer box output shaft rear bearing outer race from the transfer casing.
- Note:* Protect the transfer casing output shaft bearing bores with pads of rag to prevent damage during the following operations.

Fig. C-17—Fitting transfer box output shaft protection cap



9. Fit the protection cap (Part No. 243241) over the threaded portion of the transfer box output shaft and tap the shaft forward as far as possible to drive the front bearing outer race from the casing. Slide the shaft to the rear and insert an appropriate packing piece (Fig. C-18), between the front bearing rollers and the outer race; this packing piece may be fashioned from a scrap bearing outer race, the outer diameter of which should be ground to give free movement in the transfer box, and a portion cut away so that it may be fitted over the shaft. Tap the shaft forward again, when the bearing outer race should be driven clear of the casing.




Fig. C-18—Removing transfer box output shaft front bearing outer race
A—Packing piece

10. Part the front bearing inner race from the circlip retaining the high speed gear thrust washer by means of a mild steel chisel (Fig. C-19), then drive the front bearing inner race from the output shaft by means of brass drift.

11. Remove the circlip and thrust washer from the output shaft in front of the high speed gear, and push the output shaft through the gears clear of the casing; the high and low speed gears can then be withdrawn through the bottom of the casing.

front with its engaging teeth to the rear and the large (low-speed gear) at the rear with its selector hange to the rear.

4. Insert the output shaft through the casing and gears from the rear, engaging the splines in the low-speed gear.

5. Fit the located thrust washer in front of the high-speed gear and secure it with a circlip.

6. Fit the inner members of the two output shaft bearings to the shaft (smaller bearing at the front). The bearings must be a *light press fit* on the shaft.

7. Fit the front bearing outer race and secure it with a circlip. The bearing must be a *drive fit* in the transfer casing.

8. Fit the rear bearing outer race to the transfer casing. The bearing must be a *drive fit* in the casing.

9. Place the protection cap (Part No. 243241) on the threaded portion of transfer box output shaft (Fig. C-17) and drive the shaft until the front bearing is hard against the circlip. Lightly tap the rear bearing outer race until all the end-flare of the output shaft has been taken up.

10. Ensure that the high speed gear has .004 to .008 in. (0.10 to 0.20 mm) end-flare on the shaft, by checking with feeler gauges between the two gears. The end-flare can be increased if necessary, by grinding the located thrust washer. The end-flare of the transfer box output shaft must be adjusted to zero by means of shims between the transfer casing and speedometer drive housing. (Fitted at a later stage.)

12. Engage the transfer gear selector fork with the groove in the low speed gear, with the threaded end of the pinch bolt hole to the left-hand side.

13. Slide the selector shaft through the transfer casing and fork and secure the fork.

14. If necessary, renew the transfer box output shaft oil seal in the speedometer drive housing, with the knife edge inwards. The outer diameter of the seal should be smeared with jointing compound and the housing warmed before assembly.

15. If necessary, renew the oil seal in the speedometer drive pinion sleeve; the seal should be fitted with the knife edge inwards. Fit the pinion in the sleeve and fit the assembly to the drive housing, with the "flat" on the sleeve to the bottom. The pinion should be a *sliding fit* in the sleeve. Check that the drive functions correctly. Replace rubber 'O' ring.

16. Slide the speedometer drive worm over the transfer box output shaft with its conical end inwards and fit the dowel-located speedometer drive housing to the transfer casing, complete with suitable shims for adjustment of the transfer box output shaft bearing end-flare. The

12. If required, remove the rear bearing inner race from the output shaft by means of a suitable extractor.




Fig. C-19—Removing transfer box output shaft front bearing inner race

13. Remove the top cover plate or the power take-off selector assembly (Section T) and joint washer from the transfer casing.

14. Remove the mainshaft rear bearing assembly or the power take-off drive unit assembly and dog clutch (Section T) and joint washer from the rear of the transfer casing.

15. Remove the circlip securing the bearing in the mainshaft housing and withdraw the retaining plate and needle roller bearing. If necessary, remove the hardened steel bush from the housing, when the second plate can be withdrawn.

16. If necessary, remove the engine support brackets from the transfer casing.

17. If necessary, remove the dog clutch selector shaft bush from the transfer casing. If necessary, remove the reverse gear stop bolt and locknut from the transfer casing.

18. If necessary, remove the driving flange complete from the brake drum.

19. If necessary, remove the dust shield, circlip, bolts and retaining plate from the flange.

To assemble

Operation C/18

1. If necessary, renew the oilite bush in the transfer casing which carries the dog clutch selector shaft. The bush is made to an *interference fit* in the casing, and must be reamed to 1.148 in. (29.17 mm) after fitting.

2. Fit the two output shaft gears on the shaft and check that they mesh easily at every point of a complete revolution.

3. Remove the two gears from the shaft and place them in position in the transfer casing; the smaller (high-speed gear) should be fitted at the

shims, which are available .003 in. (0,08 mm), .005 in. (0,13 mm), .010 in. (0,25 mm) and .015 in. (0,38 mm) thick, should be selected so that the face of the rear bearing lies .002 in. (0,05 mm) below the face of the outer shim. Fig. C-20. Secure the drive housing to the transfer casing. Drive the output shaft towards the rear and ensure that it turns quite freely, but that no end-float is present; check also that the high speed gear end-float is retained.




Fig. C-20—
Adjusting
transfer box
end-float
A—Straight-edge
B—Feler gauge

24. Replace the front output shaft housing assembly. Operation C/24.
25. Fit the retaining plate and hardened steel bush in the main shaft bearing housing; fit the needle roller bearing and second retaining plate and secure with a circlip.
26. Fit the complete bearing housing (or power take-off drive unit—see Section I) to the transfer casing, together with a joint washer.
27. Fit the top cover plate (or power take-off selector assembly—see Section I) to the transfer casing, together with a joint washer.
28. Fit the gearbox unit support brackets to the transfer casing.

To refit
Operation C/20

1. Fit the complete transfer casing and joint washer to the main gearbox, locating it with two dowels. NOTE—Three self-locking nuts inside the transfer casing.

2. Replace the intermediate shaft retaining plate stud in the transfer casing.
3. Fit the intermediate shaft and cluster gear. Operation C/18—(17) and (18).
4. Fit the intermediate shaft together with the retaining plate in its deepest slot through the casing, thrust washers and gear, tapping it lightly home when the register engages.

A rubber seal is fitted to the intermediate gear shaft. This seal must be examined for wear and signs of deterioration. Renew if necessary, before refitment.

5. Fit the transfer casing bottom cover, together with a joint washer and drain plug.
6. Fit the complete transmission brake (Section H) and shield, to the speedometer drive housing, with the expander rod on the right-hand side.




Fig. C-21—Adjusting reverse gear stopbolt
A—Stop bolt
B—Locknut

20. Ensure that the gear has .004 in. to .008 in. (0,10 to 0,20 mm) end-float in the casing; if incorrect, the float can be adjusted by grinding the thrust washers or fitting a shim (.010 in. thick) behind one washer. When the end-float is correct, withdraw the shaft and remove the gear cluster from the casing complete with needle rollers and thrust washers.
21. Examine the outer diameter of the rear axle drive flange for damage which may have caused failure of the transfer box output shaft oil seal and rectify or renew the flange as necessary.
22. If removed, insert the six fitting brake drum securing bolts in the outer flange holes and fit the retaining plate over the flange. Fit the four propeller shaft securing bolts in the inner holes and secure them with a circlip.
23. Fit the dust excluder over the outer diameter of the rear axle drive flange, with the open end towards the flange.

the dog clutch selector shaft and dog clutch from the rear of the housing. Remove the top cover plate from the transfer box, hold in low transfer and slide the output shaft housing downwards and to the rear, and remove from under the vehicle. Leave the transfer selector shaft and link in position protruding from the transfer box.

Operation C/24

To strip

1. Remove the block from the transfer selector shaft.

2. Slide the following parts from the transfer selector shaft:—

Link, link pin and connector assembly, spring, spring locating bush, and distance tube.

3. Detach the link from the link pin.

Note: The connector should not be removed from the link pin unless absolutely necessary, as difficulty will be experienced in effecting correct alignment on reassembly.

4. Carefully remove the front axle drive flange complete with mudshield, avoiding damage to the oil seal.

5. Remove the output shaft from the output shaft housing.

6. Remove the block from the dog clutch selector shaft.

7. Slide the two springs and selector fork from the dog clutch selector shaft.

8. If necessary, remove the two bushes from the selector fork boss.

9. If necessary, remove the spigot bush from the rear end of the front output shaft.

10. Remove the oil seal retainer complete with oil seal, joint washer and mudshield.

11. If necessary, remove the oil seal from the oil seal retainer.

12. If necessary, remove the mudshield from the oil seal retainer.

13. If necessary, withdraw the output shaft front bearing from the front output shaft housing.

14. Remove the rubber seals in front output shaft housing for transfer gear change shaft and four-wheel drive locking pin.

To assemble

1. If necessary, replace the front output shaft front bearing in the front output shaft housing. The bearing must be a *push fit* on the shaft and a *light drive fit* in the housing. Renew the shaft, bearing and housing as necessary.

7. Slide the complete drive flange over the front output shaft and secure.

8. Ensure that the drive flange abuts the speedometer drive worm and gives a positive drive to the pinion.

9. Fit the transmission brake drum. Adjust the brake—Section H.

10. Select reverse gear in the main gearbox, and adjust the stop bolt in the transfer casing so that there is .002 in. (0.05 mm) clearance between the selector shaft and bolt.

11. Replace the oil level dipstick and refill with oil. Fit the main gearbox selector cover plate.

12. Complete the assembly by reversing the removal procedure

13. Adjust the gearbox unit mounting rubbers. Operation C/4.

14. Adjust the front wheel drive rod. Operation C/24.

Front output shaft housing assembly

To remove

1. Drain off the transfer box oil.

2. Remove floor board assembly and gearbox cover. Section R.

3. Remove seat box central panel.
4. Remove front propeller shaft. Section D.

5. Remove the hand-brake expander rod from the relay lever.

6. Remove the slave cylinder bracket assembly. Operation C/2.

7. Remove the gearbox mounting securing nuts, plain washers, rubber washers, shims (if fitted) and top rubbers.

8. Remove the transfer control link from the selector shaft; remove the transfer lever.

9. Remove the dust cover from the front of the output shaft housing.

10. Remove the front wheel drive control lever assembly. Remove the locking peg from the lever. Disconnect the operating rod from the lever (spring-loaded clevis). If necessary, press out the bush from the lever.

11. Place a jack under the gearbox and raise it as much as possible and remove the front output shaft housing complete with output shaft, front wheel drive dog clutch, the dog clutch selector shaft and fork and a joint washer. Withdraw


selector shaft and secure with the castle nut and split pin.

15. If they have been separated, the position of the connector and link pin should now be adjusted as follows:—

16. (a) The most efficient method of carrying out this operation is to use a dummy front output shaft housing with a large aperture in the side through which the connector securing nut can be tightened. Place the

Fig. C-22—
Setting the link
pin

- A—Link pin
- B—Connector
- C—Link pin
- D—Locking peg
- E—Transfer selector shaft
- F—Dog clutch selector shaft



dummy housing over the selector shafts and locate the link pin by means of the locking nut, peg. Tighten the connector securing nut, withdraw the peg, and remove the housing.

(b) If a dummy housing is not available, the actual output shaft housing can be used to align the selectors by sliding it over the shafts back to front. Proceed as follows:—

Remove the pinch bolt securing the selector fork to the transfer selector shaft and withdraw the shaft. Engage the transfer selector shaft, link pin and dog clutch selector shaft into the front face of the front output shaft housing ensuring that the link engages the pivot screws of the transfer and dog clutch selector shafts. Locate the link pin in the housing by means of locking peg and tighten the connector nut.

Remove the locking peg and withdraw the shafts and link pin from the housing. Slide the transfer selector shaft through the transfer casing and fork, and secure the fork.

17. Fit the output shaft in its housing. Examine the outer diameter of the front axle drive flange for damage which may have caused failure of the original oil seal; rectify or renew as necessary. Fit the flange and dust shield to the front output shaft.

Examine the rubber seals for transfer gear change shaft and four-wheel drive locking pin, for signs of wear or deterioration. Renew seals if necessary and replace in respective bores.

2. If removed, fit a new oil seal in the retainer with its knife edge inwards. The external diameter of the oil seal must be smeared with joining compound and the retainer warmed before assembly.

3. If removed, replace the mudshield on the oil seal retainer.

4. If removed, replace the spigot bush in the rear end of the front output shaft, pressing it in flush with the face of the shaft.

The bush must be reamed in position to $.8755 + .0005$ ($22.2 \text{ mm} + 0.013$), and should be a *sliding fit* on the transfer box output shaft.

5. If removed, renew the two oilite bushes in the dog clutch selector fork boss, pressing them flush with the end faces of the boss. They must be reamed in position to $.6255 \text{ in.} + .0005$ ($15.887 \text{ mm} + 0.012$) and should be a *sliding fit* on the selector shaft.

6. Check the two dog clutch selector springs and renew as necessary. Free length should be 2.75 in. (69.8 mm.)

7. Check the transfer selector shaft spring and renew as necessary. Free length should be 7.156 in. (181.76 mm.)

8. Replace the oil seal retainer on the front output shaft housing.

9. Fit the two springs and selector fork (crank to the rear) over the dog clutch selector shaft.

10. Replace the block on the selector shaft.

11. If the connector has been detached from the link pin, replace it with the hole for the locking peg vertical and the cutaway on the link pin underneath; ensure that the connector is square with the pin and secure *lightly* with the nut and shakeproof washer.

12. Secure the link to the link pin by means of the special screw, castle nut and split pin. The threaded end of the screw must be downwards and the shorter end of the link towards the transfer selector, with the longer arm of the jaw at the opposite end to the rear.

13. Replace the transfer shaft selector spring and plunger and secure with the plug and joint washer.

14. Slide the following parts on to the transfer selector shaft:—

Distance tube, spring locating bush with its smaller diameter to the front, and spring. Compress the spring and fit the link and connector assembly until the block is over the hole in the shaft. Fit the special screw from the bottom, through the coupling jaw, block and




Fig. C-23—
Setting transfer and dog clutch
selector shafts

To refit

Operation C/28

1. Fit the front output shaft housing joint washer.
2. Engage the dog clutch selector fork with the groove in the locking dog.
3. Engage the selector shaft into the bush in the transfer box, and at the same time slide the dog clutch over the splines on the transfer box output shaft, ensuring that the link engages the screw correctly.
4. Select low transfer (through the aperture in the transfer box). Place the housing over the selector shafts (from under) and secure to the transfer casing, picking up the earth lead under one of the nuts.
5. If necessary, renew the bush in the front wheel drive control. Connect the operating rod and locking peg to the lever.
6. Replace the control lever assembly.
7. The joint faces of dust cover shield and front output shaft housing should be smeared with Bostik sealing before refitment. Secure cover using three set bolts.

8. Replace the transfer lever. Secure the lever to the selector shaft by means of the control link.
9. Reconnect hand brake expander rod to the relay lever.
10. Replace the transfer gear change cover plate.
11. Refill the transfer box with oil of the correct grade.
12. Complete the assembly by reversing the sequence of removal operations.
13. Adjust the gearbox unit mounting rubbers. Operation C/4.
14. Adjust the front wheel drive rod to ensure sufficient extraction and replacement of the locking peg; proceed as follows:—
 - (a) Depress the four-wheel drive control rod.
 - (b) Screw down the knob locknut until the compressed spring length is $2\frac{1}{8}$ in.— $\frac{1}{16}$ (58 mm—1).
 - (c) Fit knob and tighten locknut.




Fig. C-24—
Cross-section
of reverse
stop

Main gear change lever

To overhaul

1. Remove front wheel drive control knob, locknut and spring; remove the knob and locknut from the transfer gear change lever.

2. Remove the floor board assembly and gearbox cover—Section R.

3. Remove the gear change mounting plate and gear change lever complete.

4. Remove the gear change lever housing from the mounting plate.

5. Remove the circlip from the lever housing and draw out the spring retaining washer, spring and spherical seat; withdraw the gear lever from the housing. If necessary, remove the lever ball locating pin from the housing.

6. Detach the two springs from the reverse stop hinge. Remove the reverse stop hinge (complete with adjusting screw and locknut) and the spring bracket from the reverse selector.

7. Renew the worn components.

8. Replace the lever ball locating pin in the housing (if removed on stripping) and secure it by staking.

9. Fit the gear change lever in the housing; replace the spherical seat, spring and retaining washer and secure the whole with a circlip.

10. Fit the housing to the mounting plate with the locating pin on the right-hand side.

11. Fit the reverse stop hinge and spring bracket to the reverse selector and secure them by means of two plain washers, one lockplate and two set bolts (the plain washers should be fitted under the lockplate). Replace the two reverse stop springs.

12. Fit the mounting plate to the gearbox unit.

13. Adjust the reverse stop. Operation C/32.

14. Replace the floor board assembly and gearbox cover—Section R.

Reverse stop

To adjust

1. The screw and locknut on the reverse stop hinge should be adjusted so that:—

(a) The hinge rides easily up the gear lever when reverse gear is selected, and

(b) Appreciable resistance is felt on moving the gear lever to the reverse position.

2. This adjustment should be carried out on any gearbox removed for attention, before the gearbox cover is fitted.

3. It can be carried out at any time after selecting reverse gear and sliding the access panel up the front wheel drive control rod.




Fig. C-25—Adjusting reverse stop
A—Adjusting screw B—Locknut

DEFECT LOCATION

(Symptom, Cause and Remedy)

- A—GEARBOX NOISY IN NEUTRAL**
1. Primary pinion bearing worn—*Renew.*
 2. Constant mesh gears incorrectly matched or badly worn—*Renew.*
 3. Layshaft bearing worn—*Renew.*
 4. Insufficient oil in gearbox or incorrect grade of oil—*Replenish.*
- B—GEARBOX NOISY IN GEAR**
1. Worn speedometer gear—*Renew. See Section Q.*
 2. If the gearbox is noisy in all gears except top, the constant mesh gears may be worn or incorrectly paired or the layshaft bearings may be worn—*Renew the constant mesh gears or the layshaft bearings.*
 3. Noise in either the 1st, 2nd or 3rd speed gear only, due to wear—*Renew the gear or pair of gears.*
 4. Noise in all gears in all probability denotes worn primary or mainshaft bearings—*Renew bearings and check gear teeth for wear.*
- C—OIL LEAKS FROM THE GEARBOX**
1. Lubricant level too high—*Correct level.*
 2. Damaged, incorrectly fitted or missing joint washers—*Renew.*
 3. Damaged or incorrectly fitted oil seals—*Renew.*
 4. Drain or level plugs loose or threads damaged—*Rectify.*
 5. Cracked or broken gearbox housing—*Renew.*
- D—DIFFICULTY IN ENGAGING GEARS**
1. Incorrect adjustment of the gear change mechanism—*Adjust.*
 2. Failure to release the clutch completely—*In the hands of the operator.*
 3. Clutch spinning or sticking on the pinion shaft—*Section B.*
- E—DIFFICULTY IN DISENGAGING GEARS**
1. Incorrect adjustment of the gear change mechanism—*Adjust.*
 2. Failure to release the clutch completely—*In the hands of the operator.*
 3. Clutch spinning or sticking on the pinion shaft—*Section B.*
- F—DIFFICULTY IN ENGAGING REVERSE**
1. Bush loose in gear—*Replace.*
 2. Faulty stop setting on selector forks—*Adjust.*
- G—GEAR LEVER GOING INTO REVERSE TOO EASILY AND NOT INTO FIRST**
1. Stop requires setting on selector shafts—*Adjust.*
- H—TRANSFER OF OIL FROM TRANSFER BOX TO GEARBOX, TO CLUTCH**
1. Faulty oil seal, gearbox to transfer box—*Fit new seal and sleeve.*
- I—JUMPING OUT OF HIGH TRANSFER**
1. Selector spring too weak—*Renew.*
- K—JUMPING OUT OF LOW TRANSFER**
1. Transfer selector fork assembled wrongly on shaft—*Assemble fork with set towards rear of vehicle.*
 2. Too much end-float on intermediate gear—*Adjust.*
 3. Selector spring too weak—*Renew.*
- L—NOISY TRANSFER BOX**
1. Too much end-float on intermediate gear—*Adjust.*
 2. End-float on output shaft—*Adjust.*
 3. Worn bearings—*Renew.*
- M—CANNOT ENGAGE FOUR-WHEEL DRIVE**
1. Maladjustment of return spring for yellow knob—*Adjust.*
 2. Shafts sticking in bores of casing—*Rectify.*

GENERAL DATA

Transfer box		Main gearbox	
		High ratio	Low ratio
Top gear	5.396	13.578	18.707
Third gear	7.435	11.026	27.742
Second gear	11.026	16.171	40.688
First gear	16.171	13.745	34.585
Reverse gear	13.745		

Overall gear ratios:

Front axle drive:

Type Dog clutch in transfer box
 To engage Depress yellow knob on gearbox cover
 To dis-engage Automatic by selecting low transfer, then re-verting to high transfer. Automatically engaged on selection of low transfer

Speedometer drive:

Ratio 5 to 11
 Position At rear of transfer box

Transmission brake:

Type Mechanical. (See Section H.) On transfer box output shaft

Main gearbox

Type Four speed and reverse
 Oil capacity 2½ pints (1,5 litres)

Early models:

Dipstick position L.H. rear of casing

Late models:

Oil level plug L.H. side of casing

Gear ratios:

Top 1 to 1

Third 1.377 to 1

Second 2.043 to 1

First 2.996 to 1

Reverse 2.547 to 1

Transfer gearbox:

Type Two-speed gear in main gearbox output, in unit with main gearbox

Oil capacity 4½ pints (2,5 litres)

Gear ratios:

High 1.148 to 1

Low 2.888 to 1

DETAIL DATA

Output shaft front and rear bearings—	End-float Zero	Main gearbox:	Reverse gear bush—	Reamed bore812 in. + .001 (20 mm + 0,025 mm)
High-speed gear—	End-float004 to .008 in. (0,10 to 0,20 mm) (after adjusting output shaft end-float)	Mainshaft bush—	Fit in gears	Fit in gears0015 to .002 in. (0,0375 to 0,051 mm) clearance
Intermediate gear—	End-float004 to .008 in. (0,10 to 0,20 mm)	Fit on shaft	Fit on shaft	Fit on shaft005 to .002 in. (0,0125 to 0,051 mm) clearance
			End-float	End-float	End-float001 to .008 in. (0,025 to 0,20 mm)
Front output shaft housing assembly:			2nd and 3rd speed gears—	End-float on distance sleeve	End-float on distance sleeve004 to .007 in. (0,10 to 0,177 mm)
Transfer selector shaft, spring—	Free length 7.156 in. (181,76 mm)	Synchronizing clutch-load	Load	Load 15-20 lb. (6,5-9 kg)
Transfer selector shaft, springs—	Free length 3.875 in. (98,43 mm)	2nd gear stop—	Adjustment	Adjustment002 in. (0,05 mm) clearance
Dog clutch selector springs—	Free length 2.75 in. (69,8 mm)	Reverse gear stop—	Adjustment	Adjustment002 in. (0,05 mm) clearance
	Solid length64 in. (16,2 mm)	Dog clutch selector shaft bush—	Reamed bore	Reamed bore 1.148 in. — .001 (29,17 mm — 0,025 mm)
	Maximum load 13 lb. (5,9 kg)	Transfer gearbox:			

