


# DISASSEMBLY OF TRANSFER

(See page [TF-7](#))

1. REMOVE No. 1 SPEED SENSOR
2. REMOVE TRANSFER INDICATOR SWITCH




### 3. REMOVE FRONT COMPANION FLANGE

(a) Using a hammer and chisel, loosen the staked part of the nut.

(b) Using SST to hold the flange, remove the nut and washer.

SST 09330-00021

(c) Remove the companion flange.



HINT: If the companion flange is difficult to remove, use SST.

### 4. REMOVE REAR COMPANION FLANGE

(a) Using a hammer and chisel, loosen the staked part of the nut.



(b) Using SST to hold the flange, remove the nut and washer.

SST 09330-00021


(c) Remove the companion flange.

### 5. REMOVE EXTENSION HOUSING

Remove the seven bolts and remove the extension housing.




### 6. REMOVE SPEEDOMETER DRIVE GEAR, STEEL BALL, OIL PUMP SCREW AND BEARING



## 7. REMOVE REAR CASE

- (a) Remove the ten bolts.
- (b) Using a plastic hammer, remove the rear case with the idler gear.


**HINT:** Hold the front case so the rear does not descend. If it descends, the clutch hub and steel ball may fall out.



## 8. REMOVE IDLER GEAR FROM REAR CASE


- (a) Using snap ring pliers, remove the snap ring.
- (b) Using a plastic hammer, tap out the idler gear from the rear case.

**HINT:** Place the rear case on something soft such as wooden blocks.




## 9. REMOVE BEARING RETAINER

Remove the four bolts and remove the bearing retainer.




## 10. REMOVE FRONT DRIVE GEAR

- (a) Using snap ring pliers, remove the snap ring.
- (b) Using a plastic hammer, tap out the front drive gear from the front case.




## 11. REMOVE OIL PIPES



Using pliers, remove the two oil pipes.

**12. REMOVE SHIFT NO. 1 FORK AND CLUTCH SLEEVE**


- (a) Shift the fork shafts to the high–low position.
- (b) Using a pin punch and a hammer, drive out the slotted spring pin.
- (c) Remove the shift No. 1 fork together with the clutch sleeve.

**13. REMOVE CLUTCH HUB AND TRANSFER DRIVE GEAR**


Using SST, remove clutch hub and transfer drive gear.  
SST 09950–20017

**14. REMOVE NEEDLE ROLLER BEARING, NO.2 SPACER AND STEEL BALL****15. REMOVE TRANSFER CASE COVER**

Remove the four bolts and remove the transfer case cover and gasket.

**16. REMOVE STRAIGHT SCREW PLUGS, SPRINGS AND LOCKING BALLS**


- (a) Using SST, remove the plug on the right side.  
SST 09313–30021
- (b) Using a magnetic finger, remove the spring and ball.
- (c) Remove the plug, spring and ball on the left side in the same procedure.



**17. REMOVE FRONT DRIVE SHIFT FORK SHAFT**

**18. REMOVE INTERLOCK PIN**


Using a magnetic finger, remove the interlock pin.



**19. REMOVE HIGH AND LOW SHIFT FORK SHAFT**


(a) Using a pin punch and a hammer, drive out the slotted spring pin.

(b) Remove the shaft.




**20. REMOVE FRONT CASE**


(a) Remove the four bolts.



(b) Using a plastic hammer, remove the front case with the output shaft.




**21. REMOVE NO.2 FORK WITH CLUTCH SLEEVE AND NEEDLE ROLLER BEARING FROM INPUT SHAFT**



**22. REMOVE INPUT GEAR AND COUNTER GEAR FROM REDUCTION GEAR CASE**


- (a) Using a snap ring pliers, remove the two snap rings.
- (b) Using a plastic hammer, tap out the input gear and counter gear from the reduction gear case.

HINT: Place the reduction gear case on something soft such as wooden blocks.




**23. REMOVE OUTPUT SHAFT FROM FRONT CASE**

- (a) Remove the four bearing retainer bolts and remove the bearing retainer.



- (b) Using a snap ring pliers, remove the snap ring.
- (c) Using a plastic hammer, tap out the output shaft from the front case.

HINT: Place the front case on something soft such as wooden blocks.



**24. INSPECTION OF TRANSFER INDICATOR SWITCH**

Check that there is continuity between terminals as shown.

Switch Position	Specified
Push	Continuity
Free	No continuity

If operation is not as specified, replace the switch.